

**Zepf Change Parts System
MARK II**



Features:

- Light-weight components weighing 15 lbs. (7 kg) or less
- No tools
- No loose hardware
- Fourteen color options
- Feedscrews designed for all container shapes
- Immediate production start-up
- Superior quality and delivery
- Commitment to legendary customer service
- Innovative solutions
- Great for upgrading existing machinery
- Available for all new machines

Barry-Wehmiller

Zepf Change Parts System MARK II



PneumaticScaleAngelus is dedicated to offering complete engineering, manufacturing, and support services using cutting edge technology for container handling systems. We have named our combined upgraded technology the “MARK II” Zepf Change Parts System.

The process of specially developed computer software for the design and manufacture of container handling components results in a system which sets the standards for ease and consistent speed of line changeovers.

The MARK II system is typically composed of a set of durable permanent stainless steel starwheel mounting cores, guide plates, and/or turret cores. To these are added the light weight UHMW change parts that have been designed precisely to conform to container geometry. Feed-screws are designed for all container shapes.



The combination of permanent cores and removable plastic components assure that no MARK II component involved in a changeover weighs more than fifteen pounds. Additionally, changeover of the MARK II System is accomplished with no tools whatsoever, and the System has been constructed with no loose hardware.

Efficiency of changeover is further enhanced by our ability to provide fourteen color options for correlating a complete line of different machinery to a specific container. No-tool changeover is accomplished by using our quick-change, no-time starwheels and guides.

The ongoing focus of PneumaticScaleAngelus is to provide the packaging industry with change part systems of superior quality and a level of services and innovations that consistently meets or exceeds the expectations of the customer. Rely on PneumaticScaleAngelus to provide the total solution for your container handling requirements.

PneumaticScaleAngelus Corporation

10 Ascot Parkway • Cuyahoga Falls, OH 44223 USA • 330/923-0491
5320 140th Avenue North • Clearwater, FL 33760 USA • 727/535-4100
4900 Pacific Boulevard • Los Angeles, CA 90058 USA • 323/583-2171
Belcrownlaan 44 • B-2100 Deurne, Belgium • +32 3 327-3140

De 'Salis Drive, Hampton Lovett • Ind. Est. • Droitwich, Worcester WR9 0QE, U.K. • +44 1905 779602
www.PSAngelus.com